

Oxypot 4 / V9 Instructions











Components	Oxypot 4	Oxypot V9	
Tank	1	1	
Lid	1 (5 Holes)	1 (9 Holes)	
Basket	4	9	
Сар	1	1	
Air Stone	4	4	
Air Pump	1	1	
1.5m Air line tube	6	6	
Blue air line Ts	2	2	

Instructions:

- 1. Fit 2x air line tubes to the pump outlets
- 2. Connect the opposite end of each of these air line tubes to the base of each T
- 3. Connect the 4x air stones to the end of the 4 air line tubes
- 4. Place air stones in the round locators in the tank
- **5.** Connect the open ends of the air line tubes to the Ts
- **6.** Place the lid on the tank and position the air lines to run through the spaces provided
- 7. Place the baskets in position
- 8. To use one hole as an access point, simply cover with the cap provided

Handy Tip

Reverse your lid, lowering plants further into nutrient solution, whilst roots establish.

SPECIFICATIONS	L	W	Н	VOL	NOTES
OXYPOT 4	830mm	830mm	380mm	110L	up to the base of the basket
OXYPOT V9	830mm	830mm	380mm	110L	up to the base of the basket
TANK	795mm	795mm	300mm	110L	-
LID	830mm	830mm	80mm	N/A	-